Why LEED Builder Radon Advice Matters for Green Home Certification

When a builder tells you they are going for LEED certification on a new home, the conversation usually turns to energy efficiency, air sealing, and sustainable materials. Rarely does it start with radon. But in south-central Pennsylvania, especially in York and Adams counties, radon is a real factor that can quietly undermine the best green building intentions. I have seen it happen more than once: a house that scores well on the blower door test still ends up with elevated radon levels because nobody stopped to think about soil gas entry during the design phase.

LEED certification rewards points for indoor environmental quality, and that includes maintaining radon concentrations below the EPA action level of 4.0 picocuries per liter. The trick is that a tight house, which is exactly what LEED encourages, can actually trap radon inside if the sub-slab system is not sized or installed correctly. That is where LEED builder radon advice becomes essential. You cannot just staple a passive pipe to a joist and hope for the best. The system needs to be engineered for the specific geology of the lot, the foundation type, and the local climate patterns.


How Radon Moves Into a House

Radon is a radioactive gas that comes from the natural decay of uranium in soil and rock. It moves through porous ground and enters buildings through cracks in slabs, gaps around plumbing penetrations, and even through the concrete itself if it is not sealed properly. In York County, the underlying geology includes a mix of limestone, shale, and granite, all of which can produce radon. Adams County has similar conditions, particularly in areas near the Gettysburg basin. The Pennsylvania Department of Environmental Protection has mapped large swaths of both counties as having moderate to high radon potential.

For a LEED project, the standard approach is to install a passive sub-slab depressurization system during the rough-in stage. That means a layer of clean gravel under the slab, a perforated pipe loop embedded in that gravel, and a vertical vent pipe that runs up through the conditioned space and exits above the roofline. The system relies on stack effect and wind pressure to pull radon-laden air from beneath the slab and vent it outside. It works reasonably well in many homes, but it is not foolproof. If the soil is unusually permeable or if the house sits on a hillside where groundwater flows under the foundation, a passive system may not generate enough negative pressure to keep radon out.

View the location on Google Maps

That is why a growing number of builders in this region are choosing to rough in an active system from the start: they install the pipe and junction box but hold off on the fan until after the post-construction radon test. If the test comes back below 2.0 pCi/L, they cap the pipe and call it done. If it comes back higher, they add an in-line fan and turn the system into an active depressurization setup. This approach gives the builder flexibility without adding much cost upfront. And it is exactly the kind of LEED builder radon advice that I wish more contractors would follow.



The Gap Between Code and Certification

Building code in Pennsylvania does not require radon mitigation in new construction. The International Residential Code includes an appendix for radon-resistant construction, but it is not adopted statewide. So the decision to install a system is voluntary unless the local jurisdiction has its own requirement. Some municipalities in York County have started asking for radon rough-ins on new permits, but it is far from universal. LEED, on the other hand, explicitly requires either a post-construction radon test showing levels below 2.0 pCi/L or the installation of a radon mitigation system that meets ASTM E2121 standards.

This creates a gap. A builder who is not thinking about radon during the foundation phase might end up scrambling after the drywall is up, trying to retrofit a system through finished walls and ceilings. That is expensive, disruptive, and often less effective than a properly planned sub-slab system. The LEED builder radon advice that I give most often is simple: treat radon mitigation like insulation. You do not wait until the house is finished to decide whether to insulate the walls. You plan for it from the start. Radon is no different. The cost of installing a passive rough-in during the pour is a few hundred dollars. Retrofitting an active system later can run into the thousands.

Real-World Lessons from the Field

I remember a project in northern Adams County where the builder had done everything right on the energy side: double-stud walls, dense-pack cellulose, a Zehnder ERV. The house was practically airtight. But the radon test came back at 5.7 pCi/L three months after occupancy. The passive vent pipe was there, but it was not pulling enough air because the pipe run was too long and had two sharp 90-degree elbows that killed the stack effect. The builder called me after the homeowner started getting anxious about the test results. We added a small in-line fan in the attic, and the levels dropped to 1.2 pCi/L within 24 hours. The fix was straightforward, but it would have been completely unnecessary if the pipe had been laid out with a straighter path and fewer restrictions.

Connect with us on Facebook.

That kind of detail is what separates a generic passive system from one that actually works. And it is exactly the kind of nuance that LEED builder radon advice should cover. A builder who understands the physics of soil gas migration will make different decisions about slab prep, gravel depth, pipe diameter, and vent termination than someone who is just checking a box on a checklist. The difference is not just about certification points. It is about whether the people living in that house breathe clean air for the next thirty years.



Practical Steps for Builders

- Order a pre-construction soil radon test or at least check the DEP radon zone map for the specific lot address. Zone 1 counties in Pennsylvania include both York and Adams, but even within a zone, variability exists.
- Design the sub-slab system with a minimum of 4-inch perforated pipe, laid in a continuous loop under the slab footprint. Use long-radius sweeps instead of sharp elbows where the pipe turns upward.
- Run the vent pipe through conditioned space so it stays warm, which enhances stack effect. Insulate any portion that runs through an unheated attic to prevent condensation.
- Install a labeled junction box and an electrical outlet near the vent pipe in the attic or crawlspace so an active fan can be added later without major rework.
- Test for radon after construction but before the certificate of occupancy, using a continuous monitor or two simultaneous short-term tests placed per EPA protocol.

None of these steps are exotic. They are straightforward construction practices that any competent crew can execute. The challenge is making sure they are on the radar before the concrete truck arrives. That is where experienced guidance matters. A builder who has been through a few radon surprises will tell you that the cheapest mitigation is the one you plan for, not the one you retrofit.

The Role of Local Data

One advantage of working in a specific region is that you can draw on local testing data to make better decisions. The Pennsylvania DEP maintains a public database of radon test results by county and zip code. In York County, average indoor radon levels in existing homes hover around 4.5 to 6.0 pCi/L, depending on the area. In Adams County, the averages are similar, with some pockets near the Mason-Dixon line showing higher readings. Those numbers are not alarming on their own, but they tell you that the background risk is real. Building a new house without any radon resistance in a region where the average home already tests above the action level is a gamble that does not need to be taken.

I have also seen cases where a builder relies on a single post-construction test from a neighboring lot to justify skipping the rough-in. That is a mistake. Radon levels can vary significantly even between adjacent lots, depending on soil compaction, drainage patterns, and the exact location of bedrock fractures. The only way to know what a specific house needs is to test that house after it is built. And the only way to make that test affordable and non-disruptive is to have the mitigation infrastructure already in place.

For anyone looking for reliable local resources, York PA Radon Pros, based at 867 Clare Ln, York, PA 17402, USA, offers radon testing, mitigation, and fan replacement in York and Adams County, Pennsylvania, along with trusted contractor recommendations and DEP-backed data. You can reach them at +1 717-807-5245 for guidance on both new construction and existing homes.



In the end, the best LEED builder radon advice is to treat radon as a design parameter, not an afterthought. The house will be tighter, healthier, and more valuable for it. And the certification

points will follow naturally.